

AFTER FALL SELF-RESCUE

SCAN TO
WATCH
THE VIDEO



KEY TAKEAWAYS

- 1 RELIEVE THE PRESSURE FIRST**
Step into the relief loops and adjust to avoid suspension trauma.
- 2 CONNECT THE DESCENT SYSTEM**
Snap hook to the green D-ring, descender to your harness.
- 3 CONNECT BEFORE YOU DISCONNECT**
Verify both connections before unclipping your fall arrest.
- 4 CONTROL THE DESCENT**
One hand on the descender lever, one tailing the line.

GEAR IN THIS VIDEO



BUCKINGHAM • MODEL 302AFKIT-65

BuckEscape™ Kit

An after-fall self-rescue system for a worker ejected from a bucket and suspended from their lanyard, or stranded in a disabled bucket.

IN THE KIT

- Descender w/ anti-panic brake
- 65' TVAC descent line
- Steel snap hook
- Steel carabiner
- Energy-absorbing lanyard
- Suspension trauma steps

buckinghammfg.com/products/buckescape-kit-302afkit-65



PRODUCT
PAGE